

S6065 -6066 Shadow ULG

**Infrared Bluetooth App
Outdoor Heater**

Instructions & Operation Manual



Safety Information:



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

When using any electrical appliance, safety precautions should always be observed. Read these instructions carefully, and retain for future reference.

When used by, or near, young children or infirm persons, supervision is necessary - young children should be supervised to ensure that they do not play with the appliance.

- Use this appliance only with the voltage specified on rating label.
- Do **NOT** use this appliance other than for its intended use.
- Do **NOT** touch hot surfaces or moving parts.
- Do **NOT** cover the grilles or place any object or material up against the unit, as this may block entry or exhaust of air.
- Do **NOT** probe any opening.

To ensure trouble free performance it is recommended that on a regular basis the unit be isolated from the power supply and a vacuum cleaner used to remove dust from the inlet and outlet grilles.

Caution:

When the heater is operated ensure the heater is not obstructed in any way. Ensure the heater can operate safely, should the heater switch on when the ambient temperature drops, or a timer activates the heater.

- Do **NOT** allow the supply cord to come into contact with heated surfaces during operation.
- Regulations require that electrical work be carried out by authorised persons. For your own safety and that of others, ensure this is done.
-  If the supply cord becomes damaged, it must be replaced by a qualified person, in order to avoid a hazard

Installation

For additional protection the installation of a residual current device (RCD) is recommended. (Refer to local electrical regulations)

Remove all packaging material (including anti-vibration pads on the lamp) and check the appliance, supply cord and the plug for signs of damage.

Pay attention to the mounting place and all mounting material. Ensure they are suitable and stable enough for mounting and holding the appliance on your chosen surface.

Before mounting, the minimum safe mounting distances and tilt angles shown in the figures must be strictly followed.

1. The distance between the bottom edge of the appliance and the floor must be at least 1.8 M.
2. There should be a distance of at least 1.5 M between the appliance and ceilings, roofs or other covers.
3. There should be a distance of at least 0.5 M at each side between the appliance and walls etc..
4. Recommended degree to mounting surface is 45°. **See figure 2.**
5. The max. swing degree is 90°

Fix the mounting bracket on the wall first. Ensuring that the area of installation is secure and firm.

Adjust the desired angle of radiation and tighten all screws. Check regularly as the screws' may loosen due to vibrations caused by wind or building movement.

Plug or hard wire into your power source.

Check to ensure that the heater is working.

Figure 1: Mounting bracket (wall bracket) and raw plugs provided. Connection from the wall to the infrared heater.






Figure 2: Minimum distances to floor, ceiling and wall.



Installation cont.

Figure 3: Mounting bracket (wall bracket) and raw plugs provided. Connection from the wall to the infrared heater.



Specifications:

Specification	S6065 Shadow	S2066 Shadow *
Voltage (V)	220-240	220-240
Power consumption (W)	2000W	3000W
Dimensions W H D mm	558 x 130 x 175	990 x 130 x 175
Weight (kg)	2.5	4.2
Infrared receiving Angle	60°±5°	
Control distance (m)	6	

*Dual remote

Bluetooth App Operation

The free Serene Bluetooth App for this heater is available to download for either your iPhone, iPad or Android device. See back page for QR codes

The Serene 'Shadow' App will allow you to connect remotely to many S6066 heaters and control them independently. **Control functions include:**

- On/Off
- Variable heat output from 0 to 100%
- Timer with auto shut off
- Password connection to heaters
- Individual heater identification and control

To download, search for '**Serene Outdoor Heater**' in your App store and add to your device.

Android



IOS




Remote Control Operation



Button	Graphic	Feature
Up Arrow		Up one heating level
Max		The heater goes directly to the highest heating level.
DOWN AROW		Down one heating level
ON		To switch the heater on: Press ON. The patio heater has a soft start function of 33% power. 4 seconds after the heater has been turned on, it will automatically switch to the last heating level used. In case of the first-time use, after 4seconds the heater will automatically switch to 100% power.
OFF		To switch the heater off: Press OFF. The heater will switch to standby mode(the receiver indicator will light up).

Remote Control



NOTE

Use 2 AAA.5V batteries in the remote control. Remove batteries when not use for long periods. The remote control function may not work if there is a barrier between the remote control and heater.

Cleaning And Maintenance

1. This appliance is manufactured from a robust and maintenance-free aluminum.
2. Before cleaning, remove the plug from the power outlet and wait until the appliance is sufficiently cooled off.
3. Wipe the appliance only with clean and lint-free cloth or a soft brush.
4. Never use abrasive cleaners, scrubbing brushes and chemical cleaners for cleaning!
5. You may use alcohol to clean the appliance.
6. To protect against electrical shock, do not immerse cord, plug, or any part of the appliance in water or other liquid.

Contacts:

HONG KONG

Head Office - Serene Industries Limited

t: +852 2325 3209

f: +852 2325 3166

e: info@serene-ind.com

w: www.serene-ind.com

Suite 1010, 15F, Block A, Alexander Industrial Building, 62 King Lam Street,
Cheung Sha Wan, Kowloon Hong Kong SAR

NEW ZEALAND

t: (+) 64 (3) 344 5550

f: 0800 437 264- Freefax

e: nzenquiry@sereneind.com

w: www.serene-ind.com

PO BOX 33501, Barrington, Christchurch 8024

AUSTRALIA

t: + 61 (3) 8354 4133

f: + 61 (3) 9699 6422

fp: +1800 561 961- Freephone


e: enquiries@serene-australia.com

w: www.serene-australia.com

Suite 201 / 175B Stephen Street, Yarraville

Melbourne VIC 3013

QR Codes



Apple



Android